















**Keep E'm Spinning**  
**Hammond & Leslie**  
**Pin Configurations**  
**and Relationships**  
 Including Relay & Motor Control  
 Beginners Visual Guide



**6H** 31H (above SN 5200), 21H, 22H, 22R, 122, 122A, 122R, 122V, 122RV, 142, 222, 222RV, 242, 122A, 122AT,

**6C** 50C, 51C, 51, 251, 351

**6W** 31W (above SN 5200) 44W, 46W, 25, 45, 47, 47R, 110, 112, 114, 116, 120, 120C, 125, 225, 145, 145A, 147, 147V, 147RV, 245, 247, 247RV, 147A

**9 Pin**  
760, 770, 825, 825U, 830, 900, 900U, 910, 925, 950, and two channel models 700 & 710 with active crossover installed

Remote Low Voltage Power Switch for Reference Only

**After Market Controls**

